

photo of the box in the cabin of the Peugeot 306

Designation



1. Not used.
2. 7.5 Computer automatic transmission (AKF) or overspeed buzzer.
3. 5 ABS computer.
4. 5 Instrument panel, central protection unit, coolant temperature control unit, automatic transmission mode selector illumination, automatic transmission relay, front passenger airbag deactivation lock.
5. 25 Reversing light switch, Automatic gearbox relay, brake light switch, daytime running light relay, engine cooling fan relay, pressure switch, compressor relay.
6. 5 Instrument panel, central protection unit, security system warning lamp, clock, trunk lighting lamp, radio antenna.
7. 30 Heated rear window and exterior mirrors.
8. 20 Central protection unit of the passenger compartment, car radio.
9. 20 Injection computer, engine cooling fan relay, electronic coolant temperature control unit.
10. 20 Hazard warning lamps, rear and front interior lamps.
11. 10 Dashboard lights, overspeed buzzer, clock, dashboard dimmer, side lights.
12. 10 Rear fog lamp.
13. Not used.
14. 30 Relay for rear power window and electric seat heaters.
15. 20 Connector for connecting the wiring of the trailer.
16. 30 Relay for front power windows and air vent.
17. 20 Horn switch.
18. 10 Front fog lamps.
19. 10 Rear position lamp.
20. 30 Ventilation, heating, air conditioning system
21. 10 Rear left side light, license plate light, front side lights.
22. 10 Relay for ventilation system, switch for heated rear window and outside mirrors.
23. 20 Cigarette lighter.
24. Not used.
25. 10 Car radio.
26. 30 Windscreen wiper and washer switch, windscreen wiper motor, wiper off timer or rain sensor relay.
27. 15 Glove box light, turn signal indicators, switch for electric adjustment of outside mirrors, local lighting, vanity mirror light, rain sensor, interior temperature sensor.



28. 15 Clock, outside thermometer, power window and seat heater relays, rear window wiper, ventilation hatch.

”

For the cigarette lighter fuse number 23, 20 A.

Relay

Assignment

- » Rain sensor relay 1
- » Rain sensor relay 2
- » Low beam relay / alarm
- » Front power window relay
- » Rear power window relay
- » Front fog lamp relay
- » Heater heater element relay, ACC
- » Relay for operation of the electric circuit of the engine / alarm / electric front lifts
- » Rear window heating timer relay
- » Direction indicator relay

Engine compartment

In the engine compartment, this box is located on the side of the battery, under a protective cover.



The box itself can be conditionally divided into two parts: conventional fuses and high power fuses (MF).

MF

1. 40A Power anti-theft device
2. 60A Power supply for electric locks, light switch, air conditioner fan, front fog lamp relay, diagnostic socket
3. 60A Computer Power Supply ABS
4. 60A Power supply + from the battery of the fuse box

Circuits protected

- 29 10 Left low beam headlight
- 30 10 Right low beam headlight
- 31 10 Left high beam headlight
- 32 10 Right high beam headlight
- 33 15 Diesel computer
- 34 10 Oxygen sensor
- 35 15 Fuel pump
- 36 20 Washer timer
- 37 40 Engine cooling fans
- 38 – Not used
- 39 40 Spare fuse for engine cooling fans
- 40 40 Engine cooling fans

Did not find an answer to your question? Ask it in the comment.

Related Posts:

1. **Peugeot 308 – fuse and relay**
2. **Peugeot 4008 – fuse and relay**

